

Aqueous Coatings

Viscosity Test Method

Required Materials:

#3 Zahn Cup
Stopwatch
Coating at 77°F

Procedure:

- 1) Check cup to ensure that hole has not been damaged.
- 2) Pour coating in cup until it slightly overflows.
- 3) Lift cup by the finger ring and begin stopwatch.
- 4) Stop the watch at the first sign of flow break.
- 5) Record time and clean up.